

Mini-boring bars starting from 4 mm working diameter, shank with clamping flange



Changing the insert

is done with a spread-key which pushes the resilient upper part off the tool holder thus allowing the easy change of a worn insert respectively the refitting with a new insert. The individual components are exactly fitted to each other and will therefore prevent overstretching of the clamping element (refer to central pict.).

In order to facilitate handling with regard to the small tool dimensions, we additionally offer an auxiliary entry device for changing the insert. Refer to page 108.

Please use our inquiry sheet on page 130 for requests of customer-specific special tooling solutions.

