


H Fineboring tools

Radial adjustment, μm -accurate adjustable

Spare parts 1 cutting edges



Tool	S	Tx	DSF	DS	Tx-bits	V	SW	G	D
H 1035-0700 R	E 1100	Tx 5	E 5400-5	E 5000	Tx 5-bit	E 2450-1	0,7	E 2608-1	E 2649-1
H 1035-0800 R	E 1100	Tx 5	E 5400-5	E 5000	Tx 5-bit	E 2450-2	0,7	E 2608-2	E 2649-1
H 1035-0900 R	E 1100	Tx 5	E 5400-5	E 5000	Tx 5-bit	E 2450-3	0,7	E 2608-3	E 2649-1
H 2850-1000 R	E 1085	Tx 6	E 5400-6	E 5000	Tx 6-bit	E 2323-1	0,9	E 2610-2	E 2649-2
H 2850-1100 R	E 1085	Tx 6	E 5400-6	E 5000	Tx 6-bit	E 2323-2	0,9	E 2610-2	E 2649-2
H 2850-1200 R	E 1085	Tx 6	E 5400-6	E 5000	Tx 6-bit	E 2323-2	0,9	E 2610-3	E 2649-2
H 2850-1300 R	E 1085	Tx 6	E 5400-6	E 5000	Tx 6-bit	E 2323-3	0,9	E 2610-4	E 2649-2
H 3570-1400 R	E 1060	Tx 8	E 5400-8	E 5001	Tx 8-bit	E 2108-1	1,3	E 2612-1	E 2649-3
H 3570-1600 R	E 1060	Tx 8	E 5400-8	E 5001	Tx 8-bit	E 2108-2	1,3	E 2612-1	E 2649-3
H 3570-1800 R	E 1060	Tx 8	E 5400-8	E 5001	Tx 8-bit	E 2108-2	1,3	E 2612-2	E 2649-3

Please note: Clamping set S contains:

1 Clamping element, 1 Sealing ring, 1 Clamping screw

- S Clamping set
- Tx Torx-screw driver (for operating clamping)
- DS Torque wrench adjustable (E 5000... / E 5001...)
- DSF Torque wrench fix (E 5400...)
- Tx-bits Torx-bits
- V Adjustment screw (taper screw)
- SW Hex key
- G Clamping screw
- D Pushing pin

Ordering numbers for spare parts see pages 127-129